

# Oase



## Pump Vault


20000, 60000, Extension

DE Gebrauchsanleitung  
EN Operating instructions  
FR Notice d'emploi  
NL Gebruiksaanwijzing  
ES Instrucciones de uso  
PT Instruções de uso  
IT Istruzioni d'uso  
DA Brugsanvisning  
NO Bruksanvisning  
SV Bruksanvisning  
FI Käyttöohje


HU Használati útmutató  
PL Instrukcja użytkowania  
CS Návod k použití  
SK Návod na použitie  
SL Navodila za uporabo  
HR Uputa o upotrebi  
RO Instrucțiuni de folosință  
BG Упътване за употреба  
UK Посібник з експлуатації  
RU Руководство по эксплуатации  
CN 使用说明书




**Pump Vault 20000**  
(87096)



**Pump Vault 60000**  
(89042)





**Pump Vault Extension**  
(89043)



PVT0010




# Pump Vault 20000




PVT001



## Pump Vault 60000




Pump Vault 60000



PVT0012

## Pump Vault 20000

## Pump Vault 60000




Aquarius Universal Premium 12000

Aquarius Eco Expert 28000




### Pump Vault 20000



[mm]

### Pump Vault 60000 + Extension




[mm]

PVT0013




## Pump Vault 20000



PVT0014



# Pump Vault 60000



**OASE GmbH**

Tecklenburger Straße 161  
48477 Hörstel | Germany

☎ +49 (0) 5454 80-0

📠 +49 (0) 5454 80-9353

✉ info@oase.com